

FSXS AND FSXS2 TROUBLESHOOTING GUIDE


1. FSXS or FSXS2 not progressing along the seam:

- a. **Verify Drill Speed:** Verify drill is operating in drill mode on speed setting 1 (lowest rpm). NOTE: Operating in other drill operation modes or speeds can reduce FSXS performance or potential damage.
- b. **Verify Material Thickness:** Verify material adjustment knob is set properly to match material thickness in use.
- c. **Adjust Seaming Pressure:** Seaming pressure adjustment knobs can play a role in tool traction. Start by adjusting both knobs equally in a clockwise direction and fine tune individually as needed.





- a. Verify material adjustment knob is set properly to match material thickness in use.
- b. The seaming pressure adjustment knobs determine how tight the seam is crimped. Start by adjusting both knobs equally in a clockwise direction and fine tune individually as needed.



- a. Verify material adjustment knob is set properly to match material thickness in use.
- b. The seaming pressure adjustment knobs determine how tight the seam is crimped. Start by adjusting both knobs equally in a counterclockwise direction and fine tune individually as needed.

4. Handle will not rotate into the closed position:

a. Adjust both seamer pressure adjustment knobs equally in a counterclockwise direction and fine tune individually as needed until the handle can be rotated to the closed position to lock the FSXS or FSXS2 on the seam.

CONTACT OUR CUSTOMER SERVICE DEPARTMENT FOR ANY QUESTIONS OR FOR MORE INFORMATION: customerservice@malcotools.com 320-274-7387 www.malcotools.com





